
DLT-B, E, L SERIES

Linear Slides | Maintenance and Assembly Procedure



Item	Qty	Name
0.4		5.1
01	1	Body
02	4	Bushing
_03	1	Tooling Plate
04	1	Nut, Stover
05	1	Piston Rod
06	1	Piston
07	1	Cap, Plug End
_08	1	Cap, Rod End
09	2	Shock Pad, Urethane
10	1	Guide Shaft
11	2	Collar, Split
15	1	Shock Pad, Urethane
40	1	Magnet

NOTE: Contact the Robohand Sales Department for a complete spare parts list with order numbers and prices.

Assembly Procedure

- 1) Lubricate and install seals.
- 2) Attach piston to piston shaft.
- 3) Install magnet on piston.
 4) Install plug endcap and retaining ring into body.
- 5) Attach piston, piston shaft, and rod end cap to body and install retainer
- 6) Install bearings and shafts into body. 7) Attach shock pads and clamp collars to rod end of shafts.
- Install tool plate on rod end of shafts, and attach cylinder rod to plate.
 Adjust clamp collars and fasten them
- in desired position.























DLT-B, E, L SERIES

Linear Slides | Maintenance and Assembly Procedure

NOTE: Contact the Robohand Sales Department for a complete spare parts list with order numbers and prices. NOTE: For accessory mounting, see

